



Relay connections from BS-D-8M-0-11 Teletype Control (Straight-8).

Move Brn/Yel wire from lug #3 to lug #5.

Move Blu/Wht wire from lug #4 to lug #5.

Move Purple wire from lug #8 to lug #9.

Move Brown wire on plug#4 from location #11 to location #7 (mates Yel/Wht from 4915).

Move Blue wire from terminal #3 to terminal #4 (end) of 181816 power resistor.

Remove spring and WRU pawl unit from slot "N" in function casting.

Connect thyristor M1 between connectors #1, #2 of on-off-local switch.

Connect thyristor M2 between connectors #2, #2L of on-off-local switch.

Connect Yel/Wht to L1, L2 positions of on-off-local switch.

Use cable ties to tie wiring.

Teletype for use on 50Hz or voltages other than 115V also require modification per dwg. D-IA-7505039-0-0.